



INSTRUCTIONS: CUT OUT TEMPLATE INCLUDING ALL 5 HOLES. THIS TEMPLATE SHOULD LAY FLAT ON FIREWALL AND ALL HOLES SHOULD LINE UP. IF SO, HYDROBOOST BRACKET WILL WORK. VERIFY BOTH DIMENSIONS ARE ACCURATE AFTER YOU PRINT TEMPLATE.